

Zuordnungsliste Relingträger Brio Art.Nr. 12174



Hersteller	Baujahr	Hersteller	Baujahr
<b>AUDI</b>		<b>NISSAN</b>	
A4 All Road	09>	Murano	05>
A6 Allroad	06>07	Quashquai+2	08>
A6 Allroad	08>	<b>PEUGEOT</b>	
<b>BMW</b>		308 S.W.	11>
X3	04>10	407 S.W.	04>
X5	00>08	1007	05>
<b>CADILLAC</b>		4007	07>
SRX	04>	Bipper Tepee	09>
<b>CHEVROLET</b>		Partner Tepee	08>
Transport	97>	<b>PORSCHE</b>	
<b>CHRYSLER</b>		Cayenne	10>
300 C Touring	04>	<b>PONTIAC</b>	
<b>CITROEN</b>		Transport	97>
Berlingo	97>	<b>RENAULT</b>	
C4 GranPicasso	06>	Espace	84>90
C-Crosser	07>	Express (Sans Girafor	92>
Nemo	09>	Koleos	08>
<b>DACIA</b>		<b>SAAB</b>	
Logan MCV	07>	9-5 Wagon	99>04
<b>DAIHATSU</b>		9-7 X	06>
Terios	06>	<b>SEAT</b>	
<b>FIAT</b>		Alhambra	96>10
Doblò	01>05	<b>SKODA</b>	
Fiorino Qubo	08>	Yeti	09>
Freemont	11>	<b>SHUANGHUAN</b>	
Panda	80>11	Ceo	06>
Stilo S.W.	01>	<b>SSANGYONG</b>	
<b>FORD</b>		Kyron	06>
C-Max 7	10>	Rodius	05>
Galaxy	96>10	<b>SUBARU</b>	
Kuga	08>	Forester	08>
S-Max	10>	Tribeca	08>
<b>HYUNDAI</b>		<b>TOYOTA</b>	
IX55	10>	Fortuner	98>
Santa Fe	10>	Land Cruiser	98>
<b>INFINITY</b>		<b>VOLKSWAGEN</b>	
EX	08>	Sharan	96>
FX	08>	Touran	03>
<b>KATAI</b>		Tuareg	07>
Gonow	06>	<b>VOLVO</b>	
<b>KIA</b>		V70	00>
Sedona	07>	XC70	04>
Sorento	02>09	XC90	02>
Sorento	10>		
Soul (railings)	08>		
<b>MERCEDES</b>			
Classe E S.W. (S212)	09>		
Classe ML	98>		
GL	06>		
GLK	08>		
<b>MITSUBISHI</b>			
Outlander (no sport)	99>		
Pajero / Pajero Sport	91>		